



www.biondoracing.com

PART NUMBERS MUSH-O, TBB-SA, TBB-SA-B

Remove the nut and washer from the coil cord by pulling the cord to straighten out the coils.

Run the coiled wire through any mounting hole. Re-install the washer and lock nut.

The wires on the button have **no polarity**, and can be used for many different applications, but most popular is for a trans brake in a racer car.

For standard Trans brake hookup:

- 1) 1 wire to 12 volt source.
- 2) 2nd wire to 12 volt terminal on Tran Brake Solenoid.

(For any other application refer to the specific provided with your electronics.)