



Installation Instructions

ELITE OUTLAW & REGULAR OUTLAW

CONTENTS IN BAG:



- 1. BUTTON W/WIRE
- 2- MALE CONNECTORS
- 2- FEMALE CONNECTORS
- 1- PIECE OF HEAT SHRINK TUBE



CLASSIC OUTLAW

NOTE: Follow same basic steps for Elite Outlaw Diagram, but feed wire through handle threw hollow pre-drilled bolt that hold handle on.

STEP 1: Remove aluim. insert cap located in top of handle with allen wrench. Loosen the set screw until cap is loose enough to pull out.

STEP 2: Feed button wire from the top hole on the handle, and out of the bottom hole. You could put a slight right bend on the wire, this will help feed the wire down and out of the bottom hole.

STEP 3: After all the wire is through the bottom hole, pull, and keep tension on the wire, and tighten the set screw with allen wrench. Or simply hold button down firm with your thumb, and then tighten set screw.

NOTE: DO NOT over tighten set screw, the threads are in the aluim. handle and can strip easy. tighten to a good snug fit.

STEP 4: Slide the heat shirnk tube over the end of the wire. Slide heat shrink all the way up the wire until it stops. You should be able to push heat shrink slightly into the bottom hole of the handle before it stops. Once you have your wire pushed up, heat up shrink tube with a heat gun. (or other source to heat the tubing)

STEP 5: (No diagram) Crimp the male/female connectors to your wires, and it's complete. There is NO polarity on the two button wires.

NOTE: THIS IS A MOMENTARY BUTTON, SO POWER IS ONLY APPLIED WHEN YOU PRESS DOWN THE BUTTON.

ELITE OUTLAW

