



## **ELITE OUTLAW**

# **Transmission Bracket Kit**

**Elite** Outlaw Transmission kit for transmission mounted cable.

Remove the two rear transmission pan bolts.

Place bracket below transmission pan rail using the spacers and bolts provided.

Number two hole is recommended on shifter bracket lever, but you can use anyone that may fit your application better.

Shifter bracket lever must point up as shown in photo below.

