



www.biondoracing.com

Part #HSA-O

Biondo Racing Harrington Switch Adjustable- Oversized

Installation Instructions

In order to mount this button you must take the cap off and the adjustable collar.

- 1) Loosen allen key on cap and remove cap.
- 2) Screw the entire collar off.
- 3) Mount the button to a flat surface of your choice using the nuts provided on the shaft. When you have the button mounted securely, reinstall collar and cap.

Wiring

- 1) COM (common) to 12 volt source.
- 2) NC (normally closed) not used.
- 3) NO (normally open) to 12 volt terminal on Tran Brake Solenoid.

(For any other application refer to the specific provided with your electronics.)

Adjustment

- 1) Adjust your reaction time to the tree by threading the aluminum sleeve up (counter clockwise) for faster release of the trans brake or down (clockwise) for slower release of the trans brake.

